

PH: 1-800-821-7670 Fax: 1-317-862-9422

EMAIL: occcontac@occoutdoors.com

## **INSTRUCTION SHEET for Garment Racks, Model# 790 Series**

**790-36 S**: 36" with single center hanging bar/**790-36 D**: 36" with two additional hanging bars **790-48 S**: 48" with single center hanging bar/**790-48 D**: 48" with two additional hanging bars **790-60 S**: 60" with single center hanging bar/**790-60 D**: 60" with two additional hanging bars

**790-36R**: 36" Boot rack/**790-48R**: 48" Boot rack/**790-60R**: 60" Boot rack

790-3B: set of 4/each 3" casters, 2 with brakes

4/each 5/8" diameter hat bars Shown with Optional Double hanging 1" diameter bars - 20" apart 56" Hanging Height 20" Wide 69" Tall with casters 1" Diameter Upright assembly 36" Long Shown with optional lower boot rack Shown with Optional 4/each 3" Diameter double ball bearing

casters. 2 with brakes

Note: Single units come with Screw Pack 20-PAK-12 (12 screws), Double units with Screw Pack #30-PAK-11 (16 screws)

- 1. Screw A [Top Center Support Assembly] to one of the B [Upright Assembly].
- 2. Then, screw **D** [Lower Support] to **B** [Upright Assembly] at the bottom center of the upright
- 3. Lay the entire assembly on the floor, with **D** [Lower Support] and **A** [Top Center Support Assembly] standing straight in the air. Insert the four 5/8" dia. **E** [Hat Bar] tubes into the holes at the end of the upright. If you have a double wide unit, you should screw the two **C** [Coat Bars] to **B** [Upright Assembly] on either side of the **A** [Top Center Support Assembly].
- 4. Add the other B [Upright Assembly] on top of the tubes and screw D [Lower Support], and A [Top Center Support Assembly] securely at three places shown. If you have a double wide unit, screw together at four places. Tighten securely.
- If you have a unit with casters, insert F [Casters] into the caster inserts in the tube ends of B [Upright Assembly]. NOTE: Install casters with brakes at opposite corners of the unit.

