





Assembly Step 1:

Attach the ' Expanded Top To the 238 Frames using specified hardware.

Assembly Step 2:

Attach the ' Expanded Seats to the 238 Frames using specified hardware.

Assembly Step 3:

Attach the 21-3/8" Braces to the ' Expanded Top and the 238 Frames using specified hardware.

Recommended Surface Mount Hardware:  
 5/16" x 5-1/2" Concrete Expansion Anchor Bolts  
 (Optional, Not Included)