

D

C

B

A

Assembly Step 1:

Attach the 4' Expanded Top To the 238 Frames using specified hardware.

Assembly Step 2:

Attach the 4' Expanded Seats to the 238 Frames using specified hardware.

Assembly Step 3:

Attach the 21-3/8" Braces to the 4' Expanded Top and the 238 Frames using specified hardware.

**Recommended Surface Mount Hardware:
5/16" x 5-1/2" Concrete Expansion Anchor Bolts
(Optional, Not Included)**

OCC Outdoors Products PH: 1-800-821-7670 EMAIL - occcontact@occoutdoors.com Fax: 1-317-862-9422
Part #: OCC-238-V8 2 2

A

B

C

D

8

7

6

5

4

4

3

2

1

8

7

6

5

4

4

3

2

1