


22 Gallon Econo-Mizer Trash Receptacle


For Fastener Pack
(FP-EMT22-CU-01)




Congratulations ! !

You have just purchased the finest recycled plastic
trash receptacle available. Enjoy ! ! !

Before assembly, please make sure all components are included.




D - Bag Holder




D - Bag Holder

(2) - Two Bag Holders
TRSA-EMT22-B-01




FP - Fastener Pack

(1) - One Fastener Pack
FP-EMT22-CU-01




E - Flat Top

(1) - Flat Top
TRP-EMT22-F-01



C - Frame Ring

(2) - Two Frame Rings
TRSA-EMT22-A-01



C - Frame Ring

• •	B - Side Board w/ Pilot Holes	• •
• •	B - Side Board w/ Pilot Holes	• •

(2) - Two Side Boards w/ Pilot Holes
TRP-EMT22-B-01

• •	A - Side Board	• •
• •	A - Side Board	• •
• •	A - Side Board	• •
• •	A - Side Board	• •
• •	A - Side Board	• •
• •	A - Side Board	• •
• •	A - Side Board	• •
• •	A - Side Board	• •

• •	A - Side Board	• •
• •	A - Side Board	• •
• •	A - Side Board	• •
• •	A - Side Board	• •
• •	A - Side Board	• •
• •	A - Side Board	• •
• •	A - Side Board	• •
• •	A - Side Board	• •

(16) - Sixteen Side Boards
TRP-EMT22-A-01

Before assembly, please make sure all fasteners are included.


72 - #12 x 2" Flat Head Phillips Screw



4 - #12 x 1-1/2" Pan Head Phillips Screw




8 - 1/4" Flat Washer



Also needed for this assembly will be the following materials:


1 - #3 Phillips Drive Bit




Step #1:

Place the (2) two Frame Rings on edge with the long edge on a flat surface as shown in the diagram above. One at a time, place (4) four Side Boards in position making sure the holes line up with the pre-drilled pilot holes in the Frame Rings. Fasten using (1) one 2" Flat Head Phillips Screw per hole.

*#12 x 2" Flat Head
Phillips Screw*



Step #2:
Repeat Step #1 for the opposite side.




Step #3:

Place (1) one Side Board w/ Pilot Holes in the center position making sure the holes line up with the pre-drilled pilot holes in the Frame Rings. Fasten using (1) one 2" Flat Head Phillips Screw per hole.

Step #4:

One at a time, place (4) four Side Boards in position making sure the holes line up with the pre-drilled pilot holes in the Frame Rings. Fasten using (1) one 2" Flat Head Phillips Screw per hole.




Step #5:

Repeat Step #3 and #4 for opposite side.

Step #6:

Turn the trash receptacle upright onto its base. Please use caution while moving. At this point in assembly the receptacle will weigh approximately 66 pounds.




Step #7:

Place the Bag Holder in the trash receptacle, using (1) one 1/4\" Flat Washer on each side of the pre-drilled holes, fasten with (1) one 1-1/2\" Pan Head Phillips Screw in to each pre-drilled pilot holes in the Side Boards.

Step #8:

Repeat Step #7 for the opposite side.



Step #9:

To place the lid on the trash receptacle, rest it on the inner ledge of the side walls.